

BẢNG GIÁ LINH KIỆN GIONEE TẠI SMARTCARE.VN CẬP NHẬT ĐẾN NGÀY 8/7/2016

Chi tiết xin liên hệ : 1900 636 039

| Model | Spare Part Catalog | DESCRIPTION | PART No. | Customer's Price |
|--------------|---------------------------|-------------------------------------|-----------------|-------------------------|
| E3 | Camera trước | 2M_Camera,FF,OV2722 | 150200082 | 200,000 |
| E3 | Camera sau | 8M_Camera,AF,OV8835 | 150500010 | 460,000 |
| E3 | Vỏ mặt trước | A_Cover_Assy,Grey | 310101132 | 150,000 |
| E3 | Thấu kính Camera | Back_Camera_Lens,Black | 360100675 | 60,000 |
| E3 | Nắp Pin | Battery_Cover,Black | 314201171 | 100,000 |
| E3 | Nắp Pin | Battery_Cover,Blue | 314201335 | 100,000 |
| E3 | Nắp Pin | Battery_Cover,Red | 314201168 | 100,000 |
| E3 | Nắp Pin | Battery_Cover,White | 314201170 | 100,000 |
| E3 | Nắp Pin | Battery_Cover,Yellow | 314201185 | 100,000 |
| E3 | Thấu kính đèn flash | Flash_Lamp_Lens | 360300063 | 60,000 |
| E3 | Cụm ăngten + B_Cover | GSM/WCDMA/BT/WIFI/GPS_Antenna+Cover | 170700777 | 100,000 |
| E3 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001670 | 1,900,000 |
| E3 | Màn hình | LCM,4.66",HD,LCD/CTP | 160300009 | 1,700,000 |
| E3 | Màn hình + Cảm ứng | | 160300132 | 1,700,000 |
| E3 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100041 | 70,000 |
| E3 | Màn loa trong | Receiver_Dustproof_Net | 351400643 | 60,000 |
| E3 | Phím ở cạnh máy | Side_Keypad,Grey | 320300791 | 60,000 |
| E3 | Ổ SIM | SIM_Card_Connector,Plug-in,1.3mm | 145500082 | 70,000 |
| E3 | Loa ngoài | Speaker,13*18*2.5mm,Shrapnel | 140300025 | 80,000 |
| E3 | Ổ thẻ nhớ | T_Flash_Connector,Plug-in,1.3mm | 145600022 | 60,000 |
| E3 | Chân sạc | USB_Connector,micro 5pin | 145200016 | 60,000 |
| E6 | Camera trước | 5M_Camera,FF,OV5648 | 150400058 | 220,000 |
| E6 | Camera sau | 8M_Camera,AF,OV12830 | 150800003 | 600,000 |
| E6 | Vỏ mặt trước | A_Cover_Assy,Black | 310101066 | 120,000 |
| E6 | Vỏ mặt sau | B_Cover_Assy,Black | 311100763 | 300,000 |
| E6 | Vỏ mặt sau | B_Cover_Protective_Film | 351600719 | 60,000 |
| E6 | Thấu kính Camera | Back_Camera_Lens,Black | 360100730 | 70,000 |
| E6 | Khay thẻ SIM | Card_Tray_Assy,Black | 316100403 | 90,000 |
| E6 | Khay thẻ SIM | Card_Tray_Assy,Silver | 316100375 | 90,000 |
| E6 | Cụm ăngten | FPC,Antenna_Small_Board,2Layer | 182000124 | 80,000 |

| | | | | |
|---------|----------------------|--|-----------|-----------|
| E6 | Cụm ăngten | | 182000125 | 80,000 |
| E6 | Keypad | | 182000121 | 70,000 |
| E6 | Cụm ăngten | GSM/WCDMA_Antenna+Box | 170700844 | 60,000 |
| E6 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100037 | 70,000 |
| E6 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001659 | 2,860,000 |
| E6 | Cảm ứng + Màn hình | TP_Assy,5.0",Black | 166300043 | 2,400,000 |
| E6 | Cảm ứng + Màn hình | TP_Assy,5.0",White | 166300036 | 2,400,000 |
| E6 | Chân sạc | USB_Connector,micro 5pin | 145200021 | 60,000 |
| E6 | Cụm ăngten | WIFI/BT/GPS_Antenna_Assy_FPC+Support | 170600143 | 60,000 |
| E7 | Camera sau | 16M_Camera,AF,OV16825 | 150900001 | 900,000 |
| E7 | Camera trước | 8M_Camera,AF,OV8835 | 150500010 | 440,000 |
| E7 | Vỏ mặt sau | B_Cover_Protective_Film | 351600873 | 60,000 |
| E7 | Cụm ăngten + B_Cover | BT/WIFI/GPS_Antenna+B_Cover,Black | 170700941 | 500,000 |
| E7 | Cụm ăngten + B_Cover | BT/WIFI/GPS_Antenna+B_Cover,White | 170700940 | 500,000 |
| E7 | Thấu kính Camera | Camera_Lens,Black | 360100757 | 90,000 |
| E7 | Cụm ăngten | GSM/WCDMA_Antenna+Box | 170700917 | 170,000 |
| E7 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001857 | 3,750,000 |
| E7 | Màn hình | LCM,5.46",FHD,LCD/CTP | 160300129 | 2,600,000 |
| E7 | Màn hình | LCM, 5.46", FHD, LCD/CTP (JDI/GFF White) | 160300173 | 2,600,000 |
| E7 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100151 | 70,000 |
| E7 | Ổ SIM | SIM_Card_Connector,Drawer_Type,1.4mm | 145500094 | 70,000 |
| E7 | Khay thẻ SIM | SIM_Tray,Black | 316100420 | 70,000 |
| E7 | Khay thẻ SIM | SIM_Tray,White | 316100414 | 70,000 |
| E7 MINI | Camera | 13M_Camera,AF,OV13850 | 150800007 | 540,000 |
| E7 MINI | Vỏ mặt trước | A_Cover_Assy | 310101280 | 90,000 |
| E7 MINI | Vỏ mặt sau | B_Cover_Assy,Black | 311100945 | 470,000 |
| E7 MINI | Vỏ mặt sau | B_Cover_Assy,White | 311100866 | 480,000 |
| E7 MINI | Cụm ăngten | BT/WIFI/GPS_Antenna+Support | 170700962 | 60,000 |
| E7 MINI | Khung máy | D_Cover_Assy,Black | 313100145 | 170,000 |
| E7 MINI | Khung máy | D_Cover_Assy,White | 313100139 | 170,000 |
| E7 MINI | Vỏ | E_Cover_Assy | 316100437 | 90,000 |
| E7 MINI | Vỏ | F_Cover_Assy | 340200641 | 60,000 |
| E7 MINI | Thấu kính Camera | Camera_Lens | 360100753 | 100,000 |
| E7 MINI | Cụm ăngten | GSM/TD_Antenna+Support | 170700961 | 70,000 |

| | | | | |
|------------|------------------------------|--|-----------|-----------|
| E7 MINI | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001906 | 2,180,000 |
| E7 MINI | Màn hình | LCM,4.7",HD LCD/CTP,White | 160300147 | 1,500,000 |
| E7 MINI | Màn hình | LCM,4.7",HD,LCD/CTP(Black) | 160300156 | 1,180,000 |
| E7 MINI | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100151 | 70,000 |
| E7 MINI | Ổ SIM (chân SIM 1) | SIM_Connector,Plug-in,0.5mm | 145500096 | 60,000 |
| E7 MINI | Ổ SIM (chân SIM 2) | SIM_Connector,Plug-in,0.5mm | 145500097 | 60,000 |
| E7 MINI | Ổ SIM (Vỏ lồng ổ SIM) | SIM_Connector,Tray,1.5mm | 145500099 | 60,000 |
| E7 MINI | Khay thẻ SIM | SIM_Tray,Black | 314400504 | 130,000 |
| E7 MINI | Khay thẻ SIM | SIM_Tray,White | 314400483 | 110,000 |
| E7 MINI | Loa ngoài | Speaker,13*18*2.5mm,Shrapnel | 140300025 | 80,000 |
| E7 MINI | Chân sạc | USB_Connector,micro 5pin | 145200080 | 60,000 |
| ELIFE S5.5 | Camera sau | 13M_Camera,AF,IMX135 | 150800008 | 600,000 |
| ELIFE S5.5 | Camera trước | 5M_Camera,FF,OV5648 | 150400065 | 230,000 |
| ELIFE S5.5 | Thấu kính Camera | Back_Camera_Lens | 360100756 | 70,000 |
| ELIFE S5.5 | Vỏ mặt sau | Back_Cover_Glass_Assy,Black | 360100785 | 210,000 |
| ELIFE S5.5 | Vỏ mặt sau | Back_Cover_Glass_Assy,White | 360100811 | 210,000 |
| ELIFE S5.5 | Tấm dán bảo vệ | Back_Glass_Protective_Film | 351600921 | 20,000 |
| ELIFE S5.5 | Mainboard | Main_PCBA,8Layer | 181002020 | 2,380,000 |
| ELIFE S5.5 | Battery | Battery,Black,S306189,2300mAh | 200200346 | 240,000 |
| ELIFE S5.5 | Battery | Battery,Black,S306189,2300mAh | 200200345 | 240,000 |
| ELIFE S5.5 | Tấm dán bảo vệ | TP_Protective_Film | 351601018 | 70,000 |
| ELIFE S5.5 | Màn hình | LCM,5.0",FHD,AMOLED/CTP,White | 160300170 | 1,530,000 |
| ELIFE S5.5 | Cáp USB | USB_Cable,Micro_5pin,White | 201000212 | 70,000 |
| ELIFE S5.5 | Tai nghe | Earphone,White | 203000389 | 130,000 |
| ELIFE S5.5 | Tai nghe | Earphone,White | 203000378 | 130,000 |
| ELIFE S5.5 | Củ sạc | Charger,100-240V,DC5.0V-1000,White | 202000589 | 100,000 |
| ELIFE S5.5 | Bao da | Leather_Cover,White | 412100174 | 120,000 |
| ELIFE S5.5 | Cụm ăngten + A_Cover | GSM/UMTS/BT/WIFI/GPS_Antenna+A_Cover,T | 170701209 | 950,000 |
| ELIFE S5.5 | Cụm ăngten + A_Cover | GSM/TD/WIFI/BT/GPS_Antenna+A_Cover | 170701083 | 950,000 |
| ELIFE S5.5 | Cụm ăngten + A_Cover | GSM/TD/BT/WIFI/GPS_Antenna+A_Cover | 170701135 | 950,000 |
| ELIFE S5.5 | Loa trong | Received_Ornament_Assy,Tarnish | 330300336 | 70,000 |
| ELIFE S5.5 | Cáp USB | USB_Cable,Micro_5pin,Black | 201000211 | 70,000 |
| ELIFE S5.5 | Tai nghe | Earphone,Black | 203000388 | 130,000 |
| ELIFE S5.5 | Tai nghe | Earphone,Black | 203000377 | 130,000 |

| | | | | |
|------------|--------------------------------------|---|-----------|-----------|
| ELIFE S5.5 | Củ sạc | Charger,100-240V,DC5.0V-1000mA,Black | 202000459 | 100,000 |
| ELIFE S5.5 | Bao da | Leather_Cover,Black | 412100175 | 120,000 |
| ELIFE S5.5 | Thấu kính Camera | Camera_Ornament,Tarnish | 314501777 | 110,000 |
| ELIFE S5.5 | Thấu kính Camera | Camera_Ornament,White | 314501806 | 120,000 |
| ELIFE S5.5 | Camera trước | Front_Camera_Support | 330101447 | 60,000 |
| ELIFE S5.5 | Tấm dán bảo vệ | Glass_Back_Cover_TP_Protective_Film_Set | 351601051 | 20,000 |
| ELIFE S5.5 | Cụm ăngten + A_Cover | GSM/TD/BT/WIFI/GPS_Antenna+A_Cover,Gold | 170701103 | 780,000 |
| ELIFE S5.5 | Màn hình | LCM,4.99",FHD AMOLED/CTP(Black) | 160300140 | 1,490,000 |
| ELIFE S5.5 | Phím nguồn | Power_Keypad,Gold | 320301004 | 70,000 |
| ELIFE S5.5 | Phím nguồn | Power_Keypad,Tarnish | 320300892 | 70,000 |
| ELIFE S5.5 | Màn hình + Cảm ứng+Khung Viên | Preprocess_Middle_Frame_Support_Assy,B | 316100529 | 1,690,000 |
| ELIFE S5.5 | Màn hình + Cảm ứng+Khung Viên | Preprocess_Middle_Frame_Support_Assy,W | 316100530 | 1,880,000 |
| ELIFE S5.5 | Loa trong | Received_Ornament_Assy,Silver | 330300346 | 60,000 |
| ELIFE S5.5 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100151 | 70,000 |
| ELIFE S5.5 | Màn loa trong | Receiver_Back_Dustproof_Net,Black | 351400734 | 60,000 |
| ELIFE S5.5 | Ổ SIM | SIM_Connector,Drawer_Type,1.4mm | 145500094 | 70,000 |
| ELIFE S5.5 | Khay thẻ SIM | SIM_Tray,Gold | 316100511 | 90,000 |
| ELIFE S5.5 | Khay SIM | | 316100519 | 90,000 |
| ELIFE S5.5 | Khay thẻ SIM | SIM_Tray,Tarnish | 316100447 | 90,000 |
| ELIFE S5.5 | Khay SIM | | 316100520 | 90,000 |
| ELIFE S5.5 | Loa ngoài | Speaker,9*16*3mm,Shrapnel | 140300027 | 80,000 |
| ELIFE S5.5 | Cụm ăngten + A_Cover | GSM/TD/BT/WIFI/GPS_Antenna+A_Cover,Gold | 170701136 | 920,000 |
| ELIFE S5.5 | Chân sạc | USB_Connector,micro 5pin | 145200021 | 60,000 |
| ELIFE S5.5 | Phím âm lượng | Volume_Keypad,Gold | 320301003 | 70,000 |
| ELIFE S5.5 | Phím âm lượng | Volume_Keypad,Tarnish | 320300891 | 70,000 |
| ELIFE S5.5 | Phím âm lượng | Volume_Keypad_Fixing_Gum | 350401476 | 60,000 |
| G2 | Camera trước | 1.3M_Camera, FF,OV9726 | 150100067 | 160,000 |
| G2 | Camera sau | 8M_Camera,AF,OV8830 | 150500008 | 480,000 |
| G2 | Vỏ mặt trước | A_Cover_Assy,Grey | 310101014 | 140,000 |
| G2 | Vỏ mặt trước | A_Cover_Assy,White | 310101015 | 150,000 |
| G2 | Vỏ mặt sau | B_Cover_Assy,Silver | 311100705 | 110,000 |
| G2 | Vỏ mặt sau | B_Cover_Assy,Tarnish | 311100704 | 80,000 |
| G2 | Nắp Pin | Battery_Cover_Assy,Grey | 314100495 | 70,000 |
| G2 | Nắp Pin | Battery_Cover_Assy,White | 314100496 | 70,000 |

| | | | | |
|----|--------------------------------------|----------------------------------|-----------|-----------|
| G2 | Cụm ăngten | BT/GPS/WIFI_Antenna+Support | 170700769 | 60,000 |
| G2 | Thấu kính Camera | Camera_Lens,Black | 360100727 | 60,000 |
| G2 | Thấu kính Camera | Camera_Ornament,Tarnish | 314501595 | 60,000 |
| G2 | Cụm ăngten | GSM/WCDMA_Antenna+Support | 170700709 | 70,000 |
| G2 | Phím nguồn | Power_Keypad,White | 320300656 | 60,000 |
| G2 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100041 | 70,000 |
| G2 | Màn loa trong | Receiver_Dustproof_Net,Black | 351400632 | 60,000 |
| G2 | Màn loa trong | Receiver_Dustproof_Net,Silver | 330300287 | 60,000 |
| G2 | Ổ SIM | SIM_Card_Connector,Plug-in,1.3mm | 145500081 | 60,000 |
| G2 | Loa ngoài | Speaker,13*18*2.5mm,Shrapnel | 140300025 | 80,000 |
| G2 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001451 | 1,950,000 |
| G2 | Màn hình | TFT_LCD,5.3",QHD | 160000471 | 850,000 |
| G2 | Phím cảm ứng | Touch_Key_LGF | 321100468 | 60,000 |
| G2 | Cảm ứng | TP_Assy,5.3",Black | 166300035 | 470,000 |
| G2 | Cảm ứng | TP_Assy,5.3",White | 166300031 | 480,000 |
| G2 | Chân sạc | USB_Connector,micro 5pin | 145200069 | 60,000 |
| G2 | Phím âm lượng | Volume_Keypad,White | 320300657 | 60,000 |
| G5 | Camera trước | 2M_Camera,FF,HI258 | 150200100 | 100,000 |
| G5 | Camera sau | 8M_Camera,AF,OV8830 | 150500015 | 370,000 |
| G5 | Vỏ mặt trước | A_Cover_Assy,Black | 310101459 | 500,000 |
| G5 | Ốp lưng nhựa | Protective_Case,White | 380900280 | 50,000 |
| G5 | Thấu kính Camera | Back_Camera_Lens,Black | 360100765 | 60,000 |
| G5 | Nắp Pin | Battery_Cover,Black | 314201506 | 90,000 |
| G5 | Nắp Pin | Battery_Cover,White | 314201468 | 90,000 |
| G5 | Thấu kính đèn flash | Flash_Lamp_Lens | 360200853 | 60,000 |
| G5 | Phím nguồn | Power_Keypad | 320300963 | 70,000 |
| G5 | Phím nguồn | Power_Keypad,Tarnish | 320301049 | 70,000 |
| G5 | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,Black | 310101482 | 1,760,000 |
| G5 | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,White | 310101483 | 1,700,000 |
| G5 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100153 | 60,000 |
| G5 | Mainboard | Main_PCBA,10Layer | 181002077 | 1,710,000 |
| G5 | Camera sau | 8M_Camera,AF,3H7 | 150500012 | 380,000 |
| G5 | Cụm ăngten + Loa ngoài | GSM/W_Antenna+Speaker,Black | 170701149 | 150,000 |
| G5 | Tấm dán bảo vệ | TP_Protective_Film | 351600931 | 60,000 |

| | | | | |
|---------|-----------------------------|---------------------------------------|-----------|-----------|
| G5 | Màn hình | LCM, 5.5", HD, LCD/CTP, Black | 160300160 | 1,180,000 |
| G5 | Tai nghe | Earphone,Black | 203000336 | 90,000 |
| G5 | Củ sạc | Charger,100-240V,DC5.0V-1000mA,Black | 202000638 | 80,000 |
| G5 | Battery | Battery,Orange,356476,2400mAh | 200200377 | 240,000 |
| G5 | Cáp USB | USB_Cable,Micro_5pin,Black | 201000128 | 20,000 |
| G5 | Cụm ăngten | GSM/W_Antenna+Box, White | 170701051 | 150,000 |
| G5 | Vỏ mặt trước | A_Cover_Assy,White | 310101367 | 630,000 |
| G5 | Củ sạc | Charger,100-240V,DC5.0V-1000mA,White | 202000639 | 80,000 |
| G5 | Tai nghe | Earphone,White | 203000338 | 90,000 |
| G5 | Cáp USB | USB_Cable,Micro_5pin,White | 201000169 | 20,000 |
| G5 | Màn loa trong | Receiver_Back_Dustproof_Net,Black | 351400829 | 60,000 |
| G5 | Loa ngoài | Speaker,13*18*2.5mm,Shrapnel | 140300025 | 80,000 |
| G5 | Phím âm lượng | Volume_Keypad | 320300964 | 70,000 |
| G5 | Phím âm lượng | Volume_Keypad,Tarnish | 320301050 | 70,000 |
| G5 | Cụm ăngten + B_Cover | WIFI/BT/GPS_Antenna+B_Cover,Black | 170701150 | 130,000 |
| G5 | Cụm ăngten + B_Cover | WIFI/BT/GPS_Antenna+B_Cover,White | 170701052 | 130,000 |
| GN708 | Cảm ứng | TP,4.5",Black | 166100232 | 670,000 |
| GN800 | Cảm ứng | 5.0",Black, MCF-050-0605 | 166100149 | 650,000 |
| GN800 | Cảm ứng | 5.0",WHITE, CT1025 | 166100094 | 650,000 |
| GN800 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001201 | 1,500,000 |
| GN800 | Màn hình | TFT, 5.0"VGA,TFT1P6405-E | 160000432 | 700,000 |
| GN800 | Cảm ứng | TP,5.0",White | 166100129 | 650,000 |
| GPAD G3 | Camera trước | 0.3M_Camera,FF,GC0329 | 150000305 | 30,000 |
| GPAD G3 | Bao da | Leather_Case,White | 412100132 | 140,000 |
| GPAD G3 | Bao da | Leather_Case,Black | 412100131 | 140,000 |
| GPAD G3 | Camera sau | 5M_Camera,AF,OV5648 | 150400054 | 270,000 |
| GPAD G3 | Vỏ mặt trước | A_Cover_Assy,Black | 310101091 | 140,000 |
| GPAD G3 | Vỏ mặt trước | A_Cover_Assy,Silver | 310101199 | 180,000 |
| GPAD G3 | Nắp Pin | Battery_Cover,Black | 314201300 | 90,000 |
| GPAD G3 | Nắp Pin | Battery_Cover,White | 314201327 | 100,000 |
| GPAD G3 | Thấu kính Camera | Camera_Lens,Black | 360200769 | 60,000 |
| GPAD G3 | Cụm ăngten + B_Cover | GSM/WCDMA/BT/GPS/WIFI_Antenna+B_Cover | 170700859 | 130,000 |
| GPAD G3 | Loa trong | Receiver,6*15*2.5mm,Shrapnel | 141100150 | 70,000 |
| GPAD G3 | Màn loa trong | Receiver_Dustproof_Net,Black | 330300315 | 60,000 |

| | | | | |
|------------------|--------------------------|----------------------------------|-----------|-----------|
| GPAD G3 | Màn loa trong | Receiver_Dustproof_Net,Silver | 330300314 | 60,000 |
| GPAD G3 | Phím ở cạnh máy | Side_Keypad,Black | 320300768 | 60,000 |
| GPAD G3 | Phím ở cạnh máy | Side_Keypad,White | 320300823 | 60,000 |
| GPAD G3 | Ổ SIM | SIM_Card_Connector,Plug-in,1.5mm | 145500015 | 60,000 |
| GPAD G3 | Loa ngoài | Speaker,13*18*2.5mm,Shrapnel | 140300025 | 80,000 |
| GPAD G3 | Ổ thẻ nhớ | T_Flash_Connector,Plug-in,1.3mm | 145600022 | 60,000 |
| GPAD G3 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001637 | 1,230,000 |
| GPAD G3 | Màn hình | TFT_LCD,5.5",FWVGA | 160000506 | 640,000 |
| GPAD G3 | Cảm ứng | TP_Assy,5.5",Black | 166300056 | 450,000 |
| GPAD G3 | Cảm ứng | TP_Assy,5.5",White | 166300057 | 420,000 |
| GPAD G3 | Chân sạc | USB_Connector,micro 5pin | 145200069 | 60,000 |
| INFINITY LOTUS | Cảm ứng | TP,4.0",White | 166100094 | 590,000 |
| INFINITY LOTUS | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001102 | 1,850,000 |
| INFINITY PASSION | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001172 | 1,100,000 |
| INFINITY PASSION | Màn hình | TFT_LCD,4.3",WVGA | 160000400 | 630,000 |
| INFINITY PASSION | Cảm ứng | TP,4.3",Black | 166100117 | 410,000 |
| INFINITY POWER | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001185 | 1,700,000 |
| INFINITY POWER | Màn hình | TFT_LCD,4.0",WVGA | 160000414 | 800,000 |
| L200 | Camera | 0.3M_Camera,FF,HYNIX (704) | 150000288 | 80,000 |
| L200 | Vỏ mặt trước | A_Cover_Assy,Black | 310100854 | 70,000 |
| L200 | Vỏ mặt sau | B_Cover_Assy,Black | 311100939 | 70,000 |
| L200 | Vỏ mặt sau | B_Cover_Assy,Green | 311100940 | 70,000 |
| L200 | Vỏ mặt sau | B_Cover_Assy,Red | 311100614 | 70,000 |
| L200 | Nắp Pin | Battery_Cover,Black | 314201464 | 60,000 |
| L200 | Tám phím bấm | Key_Dome_Assy | 321100457 | 60,000 |
| L200 | Mặt kính màn hình | LCD_Lens,Black+Silver | 360200674 | 60,000 |
| L200 | Bàn phím | Main_Keypad_Assy,Black | 320101076 | 70,000 |
| L200 | Loa trong | Receiver,6*15*2.5mm,Shrapnel | 141100135 | 70,000 |
| L200 | Ổ SIM | SIM_Card_Connector,Plug-in,1.8mm | 145500020 | 60,000 |
| L200 | Loa ngoài | Speaker,20*30*5.0mm,Lead | 140200154 | 70,000 |
| L200 | Ổ thẻ nhớ | T_Flash_Connector,Lift,1.6mm | 145600011 | 60,000 |
| L200 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001284 | 220,000 |
| L200 | Màn hình | TFT_LCD,2.4",QVGA | 160000454 | 170,000 |
| L200 | Chân sạc | USB_Connector,micro,5pin | 145200071 | 60,000 |

| | | | | |
|------|--------------------------|--------------------------------------|-----------|-----------|
| L800 | Camera | 0.3M_Camera,FF,HYNIX (704) | 150000287 | 80,000 |
| L800 | Vỏ mặt trước | A_Cover_Assy,Black | 310101002 | 80,000 |
| L800 | Vỏ mặt trước | A_Cover_Assy,Grey | 310101025 | 80,000 |
| L800 | Vỏ mặt sau | B_Cover_Assy,Champagne Gold | 311100711 | 80,000 |
| L800 | Vỏ mặt sau | B_Cover_Assy,Red | 311100736 | 80,000 |
| L800 | Nắp Pin | Battery_Cover,Black | 314201089 | 70,000 |
| L800 | Nắp Pin | Battery_Cover,Grey | 314201042 | 70,000 |
| L800 | Thấu kính Camera | Camera_Lens,Black | 360200729 | 60,000 |
| L800 | Cụm ăngten | GSM/BT_Antenna+Support+Foam | 170700728 | 70,000 |
| L800 | Tấm phím bấm | Key_Dome_Assy | 321100472 | 60,000 |
| L800 | Mặt kính màn hình | LCD_Lens,Black | 360200808 | 70,000 |
| L800 | Bàn phím | Main_Keypad_Assy,Gold | 320101067 | 80,000 |
| L800 | Bàn phím | Main_Keypad_Assy,Grey+Champagne Gold | 320100929 | 80,000 |
| L800 | Bàn phím | | 320100930 | 80,000 |
| L800 | Loa trong | Receiver,6*15*2.5mm,Shrapnel | 141100135 | 60,000 |
| L800 | Ổ SIM | SIM_Connector,Plug-in,1.5mm | 145500015 | 70,000 |
| L800 | Loa ngoài | Speaker,15*24*3.9mm,Lead | 140200155 | 70,000 |
| L800 | Ổ thẻ nhớ | T_Flash_Connector,Lift,1.6mm | 145600011 | 60,000 |
| L800 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001671 | 230,000 |
| L800 | Màn hình | TFT_LCD,2.6",QVGA | 160000411 | 180,000 |
| L800 | Màn hình | | 160000533 | 80,000 |
| L800 | Chân sạc | USB_Connector,micro 5pin | 145200016 | 60,000 |
| M1 | Camera trước | 0.3M_Camera,FF,GC0339 | 150000298 | 80,000 |
| M1 | Camera sau | 5M_Camera,FF,OV5647 | 150400028 | 220,000 |
| M1 | Vỏ mặt trước | A_Cover_Assy,Black | 310100972 | 120,000 |
| M1 | Nắp Pin | Battery_Cover,Black | 314200999 | 80,000 |
| M1 | Thấu kính Camera | Camera_Lens | 360100673 | 60,000 |
| M1 | Cụm ăngten | GSM/WCDMA/BT/WIFI/GPS_Antenna+Cover | 170700843 | 100,000 |
| M1 | Phím ON/OFF | ON/OFF_Keypad,Black | 320300702 | 60,000 |
| M1 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100037 | 70,000 |
| M1 | Loa ngoài | Speaker,11*15*3.5mm,Shrapnel | 140300010 | 70,000 |
| M1 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001675 | 1,350,000 |
| M1 | Màn hình | TFT_LCD,4.63",FWVGA | 160000485 | 570,000 |
| M1 | Cảm ứng | TP,4.7",Black | 166100237 | 350,000 |

| | | | | |
|----|--------------------------------------|---------------------------------------|-----------|-----------|
| M1 | Chân sạc | USB_Connector,micro 5pin | 145200072 | 60,000 |
| M1 | Phím âm lượng | Volume_Keypad,Black | 320300703 | 60,000 |
| M1 | Phím âm lượng | | 320300803 | 60,000 |
| M3 | Camera | 2M_Camera,FF,HI258 | 150200100 | 110,000 |
| M3 | Camera sau | 8M_Camera,AF,3H7 | 150500012 | 360,000 |
| M3 | Vỏ mặt trước | A_Cover_Assy,Black | 310101654 | 140,000 |
| M3 | Vỏ mặt trước | A_Cover_Assy,White | 310101653 | 150,000 |
| M3 | Vỏ mặt sau | B_Cover_Assy,Blue Black | 311101056 | 150,000 |
| M3 | Vỏ mặt sau | B_Cover_Assy,White | 311101035 | 150,000 |
| M3 | Nắp Pin | Battery_Cover,White | 314201337 | 80,000 |
| M3 | Vỏ mặt sau | | 314201539 | 80,000 |
| M3 | Nắp Pin | Battery_Cover_Metals_Steel_Sheet | 316100617 | 60,000 |
| M3 | Battery | Battery,Black,616087HV,5000mAh | 200200421 | 330,000 |
| M3 | Cụm ăngten | BT/WIFI/GPS/LDS_Antenna+Support,Black | 170701257 | 70,000 |
| M3 | Thấu kính Camera | Camera_Lens,Black | 360100747 | 60,000 |
| M3 | Cụm ăngten | GSM/WCDMA/LDS_Antenna+Support,Black | 170701256 | 80,000 |
| M3 | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,Black | 310101652 | 1,120,000 |
| M3 | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,White | 310101651 | 970,000 |
| M3 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100153 | 60,000 |
| M3 | Phím âm lượng | Side_Keypad_Assy,Silver | 320301092 | 60,000 |
| M3 | Loa ngoài | Speaker,11*15*3.5mm,Shrapnel | 140300042 | 100,000 |
| M3 | Mainboard | Main_PCBA,8Layer | 181002230 | 1,180,000 |
| M3 | Battery | Battery,Black,616087,5000mAh | 200200420 | 330,000 |
| M3 | Màn hình | LCM,4.99',HD,LCD/CTP,Black | 160300229 | 970,000 |
| M3 | Màn hình | LCM,4.99',LCD/CTP,Black | 160300235 | 970,000 |
| M3 | Tấm dán bảo vệ | TP_Protective_Film | 351601256 | 60,000 |
| M3 | Củ sạc | Charger,100-240V,DC5.0V-2000mA,Black | 202000687 | 150,000 |
| M3 | Cáp USB | USB_Cable,Micro_5pin,Black | 201000260 | 30,000 |
| M3 | Tai nghe | Earphone,Black | 203000458 | 70,000 |
| M3 | Tấm dán bảo vệ | Protective_Film_Set | 380800010 | 20,000 |
| M3 | Cụm ăngten | GSM/WCDMA/LDS_Antenna+Support,White | 170701254 | 90,000 |
| M3 | Cụm ăngten | BT/WIFI/GPS/LDS_Antenna+Support,White | 170701255 | 70,000 |
| M3 | Màn hình | LCM,4.99',HD,LCD/CTP,White | 160300230 | 1,040,000 |
| M3 | Màn hình | LCM,4.99',LCD/CTP,White | 160300236 | 1,040,000 |

| | | | | |
|------------|----------------------|---------------------------------------|-----------|-----------|
| M3 | Tai nghe | Earphone,White | 203000459 | 70,000 |
| M3 | Chân sạc | USB_Connector,micro 5pin | 145200074 | 60,000 |
| PASSION P2 | Camera trước | 0.3M_Camera,FF,OV7675 | 150000268 | 100,000 |
| PASSION P2 | Camera sau | 5M_Camera,AF,OV5647 | 150400026 | 300,000 |
| PASSION P2 | Vỏ mặt trước | A_Cover_Assy,Black | 310101026 | 150,000 |
| PASSION P2 | Nắp Pin | Battery_Cover_Assy,Black | 314100568 | 100,000 |
| PASSION P2 | Thấu kính Camera | Camera_Lens,Black | 360100671 | 60,000 |
| PASSION P2 | Phím âm lượng | | 182100951 | 70,000 |
| PASSION P2 | Cụm ăngten + B_Cover | GSM/WCDMA/BT/WIFI/GPS_Antenna+B_Cover | 170700814 | 150,000 |
| PASSION P2 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100037 | 70,000 |
| PASSION P2 | Phím ở cạnh máy | Side_Keypad,Black | 320300704 | 60,000 |
| PASSION P2 | Ổ SIM | SIM_Card_Connector,Plug-in,1.3mm | 145500081 | 60,000 |
| PASSION P2 | Khay SIM | | 145500084 | 60,000 |
| PASSION P2 | Loa ngoài | Speaker,9*16*3mm,Shrapnel | 140300017 | 80,000 |
| PASSION P2 | Ổ thẻ nhớ | T_Flash_Connector,Plug-in,1.3mm | 145600022 | 60,000 |
| PASSION P2 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001669 | 1,450,000 |
| PASSION P2 | Màn hình | TFT_LCD,4.5",FWVGA | 160000481 | 530,000 |
| PASSION P2 | Cảm ứng | TP,4.5",Black | 166100249 | 350,000 |
| PASSION P2 | Chân sạc | USB_Connector,micro 5pin | 145200021 | 60,000 |
| PIONEER 3G | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001123 | 950,000 |
| PIONEER 3G | Màn hình | LCM,3.2",QVGA,LCD | 160300004 | 240,000 |
| PIONEER 3G | Màn hình | | 160300005 | 240,000 |
| PIONEER 3G | Cảm ứng | TP,3.2",Black | 166100171 | 260,000 |
| PIONEER P1 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001358 | 1,000,000 |
| PIONEER P1 | Màn hình | TFT_LCD,3.5",HVGA | 160000472 | 260,000 |
| PIONEER P1 | Battery | Battery,Silver,VK415159,1500mAh | 200101043 | 110,000 |
| PIONEER P1 | Cảm ứng | TP,3.5",Black | 166100218 | 370,000 |
| PIONEER P1 | Cảm ứng | TP,3.5",White | 166100219 | 370,000 |
| PIONEER P2 | Camera trước | 0.3M_Camera,FF,HINX704 | 150000304 | 80,000 |
| PIONEER P2 | Camera sau | 2M_Camera,FF,HI253 | 150200088 | 150,000 |
| PIONEER P2 | Vỏ mặt trước | A_Cover,Silver | 310101184 | 120,000 |
| PIONEER P2 | Vỏ mặt sau | B_Cover_Assy,White | 311100781 | 120,000 |
| PIONEER P2 | Vỏ mặt sau | B_Cover_Ornament,White | 314501728 | 70,000 |
| PIONEER P2 | Nắp Pin | Battery_Cover,White | 314201262 | 80,000 |

| | | | | |
|-------------|-----------------------------|-------------------------------------|-----------|-----------|
| PIONEER P2 | Thấu kính Camera | Camera_Lens,Tarnish | 360200780 | 60,000 |
| PIONEER P2 | Thấu kính Camera | Camera_Ornament_Assy,Silver | 314501662 | 70,000 |
| PIONEER P2 | Thấu kính đèn flash | Flash_Lamp_Lens | 360300042 | 60,000 |
| PIONEER P2 | Cụm ăngten | GSM/WCDMA_Antenna+Support,White | 170700863 | 60,000 |
| PIONEER P2 | Phím nguồn | Power_Keypad,White | 320300817 | 60,000 |
| PIONEER P2 | Phím nguồn | | 320300845 | 60,000 |
| PIONEER P2 | Cảm ứng + Khung Viên | Preprocess_A_Cover_Assy,Silver | 310101183 | 420,000 |
| PIONEER P2 | Loa trong | Receiver,6*15*2.25mm,Shrapnel | 141100145 | 80,000 |
| PIONEER P2 | Loa trong | | 141100146 | 80,000 |
| PIONEER P2 | Loa ngoài | Speaker,11*15*3.5mm,Shrapnel | 140300001 | 70,000 |
| PIONEER P2 | Loa ngoài | | 140300024 | 70,000 |
| PIONEER P2 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001665 | 1,100,000 |
| PIONEER P2 | Màn hình | TFT_LCD,4.0",WVGA | 160000500 | 400,000 |
| PIONEER P2 | Phím cảm ứng | Touch_Key_LGF | 321100478 | 60,000 |
| PIONEER P2 | Cảm ứng | TP,4.0",Black | 166100314 | 260,000 |
| PIONEER P2 | Cảm ứng | TP,4.0",White | 166100315 | 260,000 |
| PIONEER P2 | Phím âm lượng | Volume_Keypad,Black | 320300847 | 60,000 |
| PIONEER P2 | Phím âm lượng | Volume_Keypad,White | 320300848 | 60,000 |
| PIONEER P2 | Cụm ăngten | WIFI/BT/GPS_Antenna+Support,White | 170600153 | 60,000 |
| Pioneer P2S | Camera trước | 0.3M_Camera,FF,GC0329 | 150000305 | 70,000 |
| Pioneer P2S | Camera trước | 0.3M_Camera,FF,HYNIX | 150000301 | 70,000 |
| Pioneer P2S | Camera sau | 5M_Camera,AF,OV5645 | 150400064 | 270,000 |
| Pioneer P2S | Thấu kính Camera | Back_Camera_Lens,Black | 360200882 | 40,000 |
| Pioneer P2S | Vỏ mặt trước | A_Cover_Assy,White | 310101445 | 140,000 |
| Pioneer P2S | Vỏ mặt sau | C_Cover,White | 312200108 | 80,000 |
| Pioneer P2S | Mainboard | Main_PCBA,10Layer | 181002137 | 920,000 |
| Pioneer P2S | Cảm ứng | TP_Assy,4.0",Black | 166300079 | 220,000 |
| Pioneer P2S | Vỏ mặt trước | A_Cover_Assy,Black | 310101548 | 170,000 |
| Pioneer P2S | Vỏ mặt sau | C_Cover,Black | 312200149 | 90,000 |
| Pioneer P2S | Tấm dán bảo vệ | TP_Protective_Film | 351601061 | 40,000 |
| Pioneer P2S | Củ sạc | Charger,100-240V,DC5.0V-500mA,Black | 202000364 | 70,000 |
| Pioneer P2S | Tai nghe | Earphone,Black | 203000432 | 40,000 |
| Pioneer P2S | Tai nghe | Earphone,Black | 203000433 | 40,000 |
| Pioneer P2S | Cáp USB | USB_Cable,Micro_5pin,Black | 201000128 | 40,000 |

| | | | | |
|-------------|--------------------------------|---------------------------------------|-----------|-----------|
| Pioneer P2S | Battery | Battery,Orange,vk415359AR,1600mAh | 200101119 | 120,000 |
| Pioneer P2S | Battery | Battery,Orange,415359AR,1600mAh | 200101126 | 120,000 |
| Pioneer P2S | Phím âm lượng | Side_Keypad_Assy,Black | 320301021 | 40,000 |
| Pioneer P2S | Cụm ăngten + khung giữa | GSM/WCDMA/BT/WIFI/GPS_Antenna+B_Cover | 170701141 | 90,000 |
| Pioneer P2S | Loa trong | Receiver,6*15*2.5mm,Shrapnel | 141100150 | 40,000 |
| Pioneer P2S | Ổ SIM | SIM_Connector,Plug-in,1.3mm | 145500083 | 60,000 |
| Pioneer P2S | Khay SIM | | 145500093 | 60,000 |
| Pioneer P2S | Loa ngoài | Speaker,9*16*3mm,Shrapnel | 140300027 | 70,000 |
| Pioneer P2S | Ổ thẻ nhớ | T_Flash_Connector,Plug-in,1.3mm | 145600022 | 60,000 |
| Pioneer P2S | Màn hình | TFT_LCD,4.0",QVGA | 160000556 | 270,000 |
| Pioneer P2S | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181002028 | 920,000 |
| Pioneer P2S | Cảm ứng | TP_Assy,4.0",Black | 166300078 | 220,000 |
| Pioneer P2S | Cảm ứng | TP_Assy,4.0,White | 166300080 | 210,000 |
| Pioneer P2S | Chân sạc | USB_Connector,micro 5pin | 145200074 | 60,000 |
| PIONEER P3 | Camera trước | 0.3M_Camera,FF,HINX704 | 150000304 | 70,000 |
| PIONEER P3 | Camera sau | 5M_Camera,AF,OVO5648 | 150400061 | 270,000 |
| PIONEER P3 | Vỏ mặt trước | A_Cover_Assy,Black | 310101249 | 120,000 |
| PIONEER P3 | Vỏ mặt trước | A_Cover_Assy,Silver | 310101316 | 100,000 |
| PIONEER P3 | Nắp Pin | Battery_Cover,Black | 314201404 | 90,000 |
| PIONEER P3 | Nắp Pin | Battery_Cover,White | 314201405 | 90,000 |
| PIONEER P3 | Mainboard | Main_PCBA,6Layer | 181001807 | 1,050,000 |
| PIONEER P3 | Cảm ứng | TP_Assy,4.3",White | 166300065 | 300,000 |
| PIONEER P3 | Phím nguồn | Power_Keypad,Silver | 320300903 | 40,000 |
| PIONEER P3 | Phím âm lượng | Volume_Keypad,Silver | 320300904 | 40,000 |
| PIONEER P3 | Thấu kính đèn flash | Flash_Lamp_Lens | 360300074 | 40,000 |
| PIONEER P3 | Thấu kính Camera | Camera_Ornament,Silver | 314501631 | 40,000 |
| PIONEER P3 | Thấu kính Camera | Black_Camera_Lens | 360200787 | 40,000 |
| PIONEER P3 | Tấm dán bảo vệ | TP_Protective_Film | 351600858 | 40,000 |
| PIONEER P3 | Phím ở cạnh máy | Side_Keypad_Rubber_Cover,Black | 340200639 | 40,000 |
| PIONEER P3 | Củ sạc | Charger,100-240V,DC5.0-500mA,Black | 202000116 | 70,000 |
| PIONEER P3 | Củ sạc | Charger,100-240V,DC5.0V-500mA,Black | 202000364 | 70,000 |
| PIONEER P3 | Tai nghe | Earphone,Black | 203000432 | 40,000 |
| PIONEER P3 | Tai nghe | Earphone,Black | 203000433 | 40,000 |
| PIONEER P3 | Cáp USB | USB_Cable,Micro_5pin,Black | 201000128 | 40,000 |

| | | | | |
|------------|-----------------------------|---|-----------|-----------|
| PIONEER P3 | Battery | Battery,Orange,VK345381,1700mAh | 200200091 | 150,000 |
| PIONEER P3 | Phím nguồn | Power_Keypad | 320300828 | 40,000 |
| PIONEER P3 | Phím âm lượng | Volume_Keypad | 320300829 | 40,000 |
| PIONEER P3 | Thấu kính Camera | Camera_Ornament,Tarnish | 314501629 | 40,000 |
| PIONEER P3 | Loa trong | Receiver,6*15*2.25mm,Shrapnel | 141100146 | 70,000 |
| PIONEER P3 | Ổ SIM | SIM_Card_Connector,Plug-in,1.5mm | 145500015 | 60,000 |
| PIONEER P3 | Loa ngoài | Speaker,11*15*3.5mm,Shrapnel | 140300024 | 60,000 |
| PIONEER P3 | Ổ thẻ nhớ | T_Flash_Connector,Lift,1.6mm | 145600011 | 60,000 |
| PIONEER P3 | Màn hình | TFT_LCD,4.3",WVGA | 160000529 | 370,000 |
| PIONEER P3 | Cảm ứng | TP_Assy,4.3",Black | 166300064 | 250,000 |
| PIONEER P3 | Chân sạc | USB_Connector,micro 5pin | 145200000 | 60,000 |
| PIONEER P3 | Cụm ăngten | WIFI/BT/GPS/GSM_Antenna+B_Cover | 170700914 | 80,000 |
| PIONEER P3 | Cụm ăngten | | 170700915 | 90,000 |
| PIONEER P4 | Camera trước | 2M_Camera,FF,HI256 | 150200102 | 150,000 |
| PIONEER P4 | Camera sau | 5M_Camera,AF,OV5648 | 150400054 | 250,000 |
| PIONEER P4 | Vỏ mặt trước | A_Cover_Assy,Black | 310101328 | 150,000 |
| PIONEER P4 | Vỏ mặt trước | A_Cover_Assy,White | 310101329 | 150,000 |
| PIONEER P4 | Thấu kính Camera | Back_Camera_Lens,Black | 360200844 | 60,000 |
| PIONEER P4 | Nắp Pin | Battery_Cover_Assy,Black | 314100743 | 90,000 |
| PIONEER P4 | Nắp Pin | Battery_Cover_Assy,White | 314100744 | 80,000 |
| PIONEER P4 | Mainboard | Main_PCBA,10Layer | 181002014 | 1,130,000 |
| PIONEER P4 | Màn hình | TFT_LCD,4.46",FWVGA | 160000575 | 410,000 |
| PIONEER P4 | Màn hình | TFT_LCD,4.46",FWVGA | 160000558 | 410,000 |
| PIONEER P4 | Cảm ứng | TP_Assy,4.5",Black | 166300075 | 280,000 |
| PIONEER P4 | Cụm ăngten + B_Cover | GSM/WCDMA/BT/WIFI/GPS_Antenna+B_Cover,B | 170701244 | 120,000 |
| PIONEER P4 | Tấm dán bảo vệ | TP_Protective_Film | 351600964 | 60,000 |
| PIONEER P4 | Battery | Battery,Orange,SL365570,1800mAh | 200200290 | 180,000 |
| PIONEER P4 | Battery | Battery,Orange,VK365570,1800mAh | 200200291 | 180,000 |
| PIONEER P4 | Battery | Battery,Orange,CA365570,1800mAh | 200200292 | 180,000 |
| PIONEER P4 | Tai nghe | Earphone,Black | 203000458 | 70,000 |
| PIONEER P4 | Cáp USB | USB_Cable,Micro_5pin,Black | 201000128 | 20,000 |
| PIONEER P4 | Củ sạc | Charger,100-240V,DC5.0V-500mA,Black | 202000364 | 50,000 |
| PIONEER P4 | Cảm ứng | TP_Assy,4.5",White | 166300076 | 300,000 |
| PIONEER P4 | Cụm ăngten + B_Cover | GSM/WCDMA/BT/WIFI/GPS_Antenna+B_Cover,W | 170701245 | 130,000 |

| | | | | |
|------------|----------------------|--|-----------|---------|
| PIONEER P4 | Tai nghe | Earphone,White | 203000459 | 70,000 |
| PIONEER P4 | Cụm ăngten + B_Cover | GSM/TD/BT/WIFI/GPS_Antenna+B_Cover,White | 170700979 | 100,000 |
| PIONEER P4 | Cụm ăngten + B_Cover | GSM/WCDMA/BT/WIFI/GPS_Antenna+B-Cover,B | 170700977 | 100,000 |
| PIONEER P4 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100151 | 60,000 |
| PIONEER P4 | Loa trong | | 141100153 | 60,000 |
| PIONEER P4 | Ổ SIM | SIM_Connector,Plug-in,1.3mm | 145500081 | 60,000 |
| PIONEER P4 | Khay SIM | | 145500084 | 60,000 |
| PIONEER P4 | Loa ngoài | Speaker,9*16*3mm,Shrapnel | 140300040 | 80,000 |
| PIONEER P4 | Ổ thẻ nhớ | T_Flash_Connector,Plug-in,1.3mm | 145600022 | 60,000 |
| PIONEER P4 | Màn hình | TFT_LCD,4.5",FWVGA | 160000547 | 400,000 |
| PIONEER P4 | Cảm ứng | TP_Assy,4.5",Black | 166300072 | 280,000 |
| PIONEER P4 | Cảm ứng | TP_Assy,4.5",White | 166300071 | 300,000 |
| PIONEER P4 | Chân sạc | USB_Connector,micro 5pin | 145200021 | 60,000 |
| POCKET | Camera | 0.3M_Camera,FF,HYNIX (704) | 150000287 | 80,000 |
| POCKET | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001152 | 750,000 |
| POCKET | Cảm ứng | TP,2.83",Black | 166100109 | 220,000 |
| S30 | Camera | 0.3M_Camera,FF,HYNIX704 | 150000079 | 80,000 |
| S30 | Vỏ mặt trước | A_Cover_Assy,Grey | 310100800 | 70,000 |
| S30 | Vỏ mặt sau | B_Cover_Assy,Gold | 311100504 | 80,000 |
| S30 | Vỏ mặt sau | B_Cover_Assy,Grey | 311100505 | 80,000 |
| S30 | Nắp Pin | Battery_Cover,Tarnish | 314300090 | 90,000 |
| S30 | Thấu kính Camera | Camera_Lens,Black | 360200570 | 60,000 |
| S30 | Thấu kính Camera | Camera_Ornament,Tarnish | 314501424 | 60,000 |
| S30 | Keypad | FPC,Keypad_FPC,2Layer | 182000092 | 60,000 |
| S30 | Cụm ăngten | GSM/BT_Antenna+Speaker_Support | 170700516 | 70,000 |
| S30 | Tám phím bấm | Key_Dome | 321100434 | 60,000 |
| S30 | Mặt kính màn hình | LCD_Lens,Black | 360200583 | 60,000 |
| S30 | Bàn phím | Main_Keypad_Assy,Grey | 320100805 | 80,000 |
| S30 | Loa trong | Receiver,6*15*2.5mm,Shrapnel | 141100135 | 60,000 |
| S30 | Màn loa trong | Receiver_Dustproof_Net,Black | 351400430 | 60,000 |
| S30 | Loa ngoài | Speaker,15*24*4.0mm,Lead | 140200061 | 70,000 |
| S30 | Cụm board bàn phím | Sub_PCBA,Keypad_Board,2Layer | 181100240 | 70,000 |
| S30 | Cụm bàn phím | | 181100241 | 70,000 |
| S30 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001664 | 300,000 |

| | | | | |
|------|-------------------------------|--------------------------------------|-----------|-----------|
| S30 | Màn hình | TFT_LCD,2.6",QVGA | 160000411 | 180,000 |
| S5.1 | Camera trước | 5M_Camera,FF,S5K5E2 | 150400084 | 170,000 |
| S5.1 | Camera sau | 8M_Camera,AF,OV8858 | 150500020 | 370,000 |
| S5.1 | Vỏ mặt trước | A_Cover_Assy,Gold | 310101494 | 1,000,000 |
| S5.1 | Vỏ mặt sau | Back_Cover_Glass_Assy,Black | 360100987 | 210,000 |
| S5.1 | Vỏ mặt sau | Back_Cover_Glass_Assy,White | 360100983 | 200,000 |
| S5.1 | Tấm dán bảo vệ | Back_Glass_Protective_Film | 351601251 | 20,000 |
| S5.1 | Ốp lưng nhựa | Protective_Case | 380900295 | 60,000 |
| S5.1 | Battery | Battery,Orange,ATL296181, 2050mAh | 200200416 | 260,000 |
| S5.1 | Cụm ăngten | BT/WIFI/GPS_Antenna+Support,Black | 170701218 | 70,000 |
| S5.1 | Mainboard | Main_PCBA,10Layer | 181002207 | 1,800,000 |
| S5.1 | Màn hình | LCM,4.8",HD,LCD/CTP,White | 160300193 | 1,220,000 |
| S5.1 | Battery | Battery,Orange,LG296181,2050mAh | 200200404 | 260,000 |
| S5.1 | Battery | Battery,Orange,ATL286181,2050mAh | 200200557 | 260,000 |
| S5.1 | Tấm dán bảo vệ | TP_Protective_Film | 351601234 | 70,000 |
| S5.1 | Cáp USB | USB_Cable,Micro_5pin,White | 201000248 | 50,000 |
| S5.1 | Tai nghe | Earphone,White | 203000389 | 130,000 |
| S5.1 | Tai nghe | Earphone,White | 203000378 | 130,000 |
| S5.1 | Củ sạc | Charger,100-240V,DC5.0V-1000mA,White | 202000693 | 100,000 |
| S5.1 | Tấm dán bảo vệ | Protective_Film_Set_Front | 380800005 | 20,000 |
| S5.1 | Tấm dán bảo vệ | Protective_Film_Set_Back | 380800006 | 20,000 |
| S5.1 | Ốp lưng nhựa | Protective_Case,White | 380900296 | 90,000 |
| S5.1 | Vỏ mặt trước | A_Cover_Assy,Coffee | 310101481 | 1,140,000 |
| S5.1 | Vỏ mặt trước | A_Cover_Assy,Coffee | 310101667 | 1,140,000 |
| S5.1 | Màn hình | LCM,4.8",HD,LCD/CTP,Black | 160300192 | 1,180,000 |
| S5.1 | Màn loa trong | Receiver_Dustproof_Net,Black | 351400957 | 70,000 |
| S5.1 | Thấu kính đèn flash | Flash_Lamp_Ornament,Tarnish | 314501903 | 70,000 |
| S5.1 | Thấu kính đèn flash | Flash_Lamp_Ornament,Tarnish | 314501904 | 70,000 |
| S5.1 | Thấu kính đèn flash | Flash_Lamp_Ornament,Silver | 314501910 | 60,000 |
| S5.1 | Cụm ăngten | GSM/WCDMA_Antenna+Box | 170701217 | 80,000 |
| S5.1 | Phím nguồn | Power_Keypad,Coffee | 320301078 | 70,000 |
| S5.1 | Phím nguồn | Power_Keypad,Gold | 320301084 | 70,000 |
| S5.1 | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,Gold | 310101588 | 2,300,000 |
| S5.1 | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,Tarnish | 310101555 | 2,250,000 |

| | | | | |
|------|---------------------------|---|-----------|---------|
| S5.1 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100153 | 70,000 |
| S5.1 | Màn loa trong | Receiver_Dustproof_Net,Silver | 351400826 | 60,000 |
| S5.1 | Ổ SIM | SIM_Connector,Drawer_Type,1.3mm | 145500102 | 70,000 |
| S5.1 | Khay thẻ SIM | SIM_Tray,Coffee | 316100541 | 80,000 |
| S5.1 | Khay thẻ SIM | SIM_Tray,Gold | 316100546 | 120,000 |
| S5.1 | Loa ngoài | Speaker, 8*18*2.5mm,Shrapnel | 140300044 | 120,000 |
| S5.1 | Phím âm lượng | Volume_Keypad,Coffee | 320301076 | 70,000 |
| S5.1 | Phím âm lượng | Volume_Keypad,Gold | 320301082 | 70,000 |
| S80 | Camera trước | 0.3M_Camera,FF,HINX (704) | 150000289 | 80,000 |
| S80 | Battery | Battery,Orange,VK424361,1280mAh | 200101008 | 100,000 |
| S80 | Cụm board bàn phím | Sub_PCBA,Keypad_Board,2Layer | 181100328 | 70,000 |
| S80 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001285 | 300,000 |
| S80 | Màn hình | TFT_LCD,2.8",QVGA | 160000525 | 220,000 |
| S90 | Camera | 0.3M_Camera,FF,HYNIX (704) | 150000292 | 80,000 |
| S90 | Vỏ mặt trước | A_Cover_Assy,Gold | 310101327 | 80,000 |
| S90 | Vỏ mặt trước | A_Cover_Assy,Grey | 310101110 | 80,000 |
| S90 | Vỏ mặt sau | B_Cover_Assy,Gold | 311100890 | 80,000 |
| S90 | Vỏ mặt sau | B_Cover_Assy,Grey | 311100888 | 80,000 |
| S90 | Nắp Pin | Battery_Cover,Gold | 314201410 | 90,000 |
| S90 | Nắp Pin | Battery_Cover,Tarnish | 314300160 | 90,000 |
| S90 | Khay SIM | Combine_Connector,Dual SIM +T_Card 3In1 | 146000000 | 60,000 |
| S90 | Cụm ăngten | GSM/BT_Antenna+Speaker_Support | 170700966 | 80,000 |
| S90 | Tấm phím bấm | Key_Dome_Assy | 321100481 | 60,000 |
| S90 | Mặt kính màn hình | LCD_Lens,Black+Silver | 360200816 | 70,000 |
| S90 | Mặt kính màn hình | LCD_Lens,Gold | 360200843 | 70,000 |
| S90 | Bàn phím | Main_Keypad_Assy,Gold | 320101063 | 100,000 |
| S90 | Bàn phím | Main_Keypad_Assy,Grey+Tarnish | 320101061 | 100,000 |
| S90 | Loa trong | Receiver,6*15*2.5mm,Shrapnel | 141100150 | 70,000 |
| S90 | Loa ngoài | Speaker,11*15*3.5mm,Shrapnel | 140300024 | 70,000 |
| S90 | Cụm bàn phím | Sub_PCBA,Keypad_Board,2Layer | 181100422 | 70,000 |
| S90 | Mainboard | Main_PCBA,Reference EBOM,10Layer | 181001783 | 250,000 |
| S90 | Màn hình | TFT_LCD,2.6",QVGA | 160000533 | 200,000 |
| S90 | Chân sạc | USB_Connector,micro 5pin | 145200069 | 60,000 |
| V4S | Camera trước | 2M_Camera,FF,HI258 | 150200100 | 140,000 |

| | | | | |
|-----|--------------------------------------|--------------------------------------|-----------|-----------|
| V4S | Camera sau | 8M_Camera,AF,P8V12K | 150500017 | 350,000 |
| V4S | Vỏ mặt trước | A_Cover_Assy,Black | 310101460 | 140,000 |
| V4S | Vỏ mặt sau | B_Cover_Assy,Silver | 311101000 | 160,000 |
| V4S | Thấu kính Camera | Back_Camera_Lens,Black | 360200879 | 60,000 |
| V4S | Nắp Pin | Battery_Cover,Black | 314201570 | 90,000 |
| V4S | Nắp Pin | Battery_Cover,White | 314201571 | 70,000 |
| V4S | Cụm ăngten | BT/WIFI/GPS_Antenna+Support,Black | 170701222 | 60,000 |
| V4S | Cụm ăngten | BT/WIFI/GPS_Antenna+Support,White | 170701168 | 60,000 |
| V4S | Mainboard | Main_PCBA,10Layer | 181002108 | 1,220,000 |
| V4S | Vỏ mặt trước | A_Cover_Assy,White | 310101563 | 190,000 |
| V4S | Màn hình | LCM,4.5',FWVGA,LCD/CTP,White | 160300237 | 790,000 |
| V4S | Tấm dán bảo vệ | TP_Protective_Film | 351601166 | 60,000 |
| V4S | Battery | Battery,Orange,VK365769,1800mAh | 200101147 | 180,000 |
| V4S | Battery | Battery,Orange,SL355567,1800mAh | 200200374 | 180,000 |
| V4S | Tai nghe | Earphone,White | 203000459 | 70,000 |
| V4S | Cáp USB | USB_Cable,Micro_5pin,Black | 201000134 | 60,000 |
| V4S | Củ sạc | Charger,100-240V,DC5.0V-1000mA,Black | 202000638 | 80,000 |
| V4S | Ốp lưng nhựa | Protective_Case,White | 380900304 | 70,000 |
| V4S | Màn hình | LCM,4.5',FWVGA,LCD/CTP,Black | 160300214 | 840,000 |
| V4S | Màn hình | LCM,4.5',FWVGA,LCD/CTP,Black | 160300212 | 840,000 |
| V4S | Màn hình | LCM,4.5',FWVGA,LCD/CTP,Black | 160300238 | 840,000 |
| V4S | Tai nghe | Earphone,Black | 203000458 | 70,000 |
| V4S | Cáp USB | USB_Cable,Micro_5pin,Black | 201000235 | 60,000 |
| V4S | Cáp USB | USB_Cable,Micro_5pin,Black | 201000128 | 60,000 |
| V4S | Ốp lưng nhựa | Protective_Case,Black | 380900303 | 70,000 |
| V4S | Cụm ăngten | GSM/WCDMA_Antenna+Support,Black | 170701223 | 60,000 |
| V4S | Cụm ăngten | GSM/WCDMA_Antenna+Support,White | 170701169 | 60,000 |
| V4S | Phím nguồn | Power_Keypad,Silver | 320301065 | 60,000 |
| V4S | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,Black | 310101608 | 930,000 |
| V4S | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,Black | 310101610 | 930,000 |
| V4S | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,White | 310101617 | 980,000 |
| V4S | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100166 | 60,000 |
| V4S | Màn loa trong | Receiver_Back_Dustproof_Net,Black | 351400734 | 60,000 |
| V4S | Phím ở cạnh máy | Side_Keypad_Mylar | 351500199 | 60,000 |

| | | | | |
|-----|---|---------------------------------------|-----------|-----------|
| V4S | Ổ SIM | SIM_Card_Connector,Plug-in,1.3mm | 145500084 | 60,000 |
| V4S | Loa ngoài | Speaker,9*16*3mm,Shrapnel | 140300039 | 70,000 |
| V4S | Ổ thẻ nhớ | T_Flash_Connector,Plug-in,1.3mm | 145600022 | 60,000 |
| V4S | Chân sạc | USB_Connector,micro 5pin | 145200074 | 60,000 |
| V4S | Phím âm lượng | Volume_Keypad,Silver | 320301064 | 60,000 |
| V5 | Camera trước | 2M_Camera,FF,HI258 | 150200100 | 100,000 |
| V5 | Camera sau | 8M_Camera,AF,OV8830 | 150500015 | 350,000 |
| V5 | Vỏ mặt trước | A_Cover_Assy,Black | 310101539 | 90,000 |
| V5 | Thấu kính Camera | Back_Camera_Lens,Black | 360200851 | 60,000 |
| V5 | Bao da | Leather_Cover | 412100162 | 90,000 |
| V5 | Vỏ mặt sau | C_Cover_Assy,Black | 312100125 | 80,000 |
| V5 | Vỏ mặt sau | C_Cover_Assy,White | 312100082 | 90,000 |
| V5 | Tấm dán bảo vệ | C_Cover_Protective_Film | 351601028 | 60,000 |
| V5 | Mainboard | Main_PCBA,10Layer | 181001918 | 1,230,000 |
| V5 | Màn hình | LCM,4.66",QHD_LCD/CTP(Black) | 160300135 | 1,110,000 |
| V5 | Màn hình | LCM,4.66",qHD,LCD/CTP,Black | 160300152 | 1,110,000 |
| V5 | Vỏ mặt sau | C_Cover_Assy,Yellow | 312100134 | 150,000 |
| V5 | Tấm dán bảo vệ | TP_Protective_Film | 351600962 | 60,000 |
| V5 | Phím ở cạnh máy | Side_Keypad_Mylar | 351500199 | 60,000 |
| V5 | Củ sạc | Charger,100-240V,DC5.0V-1000mA,Black | 202000459 | 80,000 |
| V5 | Battery | Battery,Orange,SL365570,1800mAh | 200200290 | 180,000 |
| V5 | Battery | Battery,Orange,VK365570,1800mAh | 200200291 | 180,000 |
| V5 | Battery | Battery,Orange,CA365570,1800mAh | 200200292 | 180,000 |
| V5 | Tai nghe | Earphone,White | 203000459 | 70,000 |
| V5 | Cáp USB | USB_Cable,Micro_5pin,Black | 201000128 | 60,000 |
| V5 | Bao da | Leather_Cover,White | 412100164 | 90,000 |
| V5 | Màn hình | LCM,4.66',QHD,LCD/CTP,White | 160300219 | 1,130,000 |
| V5 | Vỏ mặt trước | A_Cover_Assy,White | 310101542 | 150,000 |
| V5 | Tai nghe | Earphone,Black | 203000458 | 70,000 |
| V5 | Bao da | Leather_Cover,Black | 412100163 | 90,000 |
| V5 | Bao da | Leather_Cover,Black | 412100161 | 90,000 |
| V5 | Khung sườn sau + Ăngten Wifi/Gps | GSM/WCDMA/BT/WIFI/GPS_Antenna+B_Cover | 170701009 | 100,000 |
| V5 | Cụm ăngten | | 170701010 | 100,000 |
| V5 | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,Black | 310101534 | 1,090,000 |

| | | | | |
|----|---|---|-----------|-----------|
| V5 | Màn hình + Cảm ứng+Khung Viên | Preprocess_A_Cover_Assy,White | 310101537 | 1,140,000 |
| V5 | Màn loa trong | Received_Ornament,Silver | 314501808 | 60,000 |
| V5 | Màn loa trong | Received_Ornament,Tarnish | 314501798 | 60,000 |
| V5 | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100151 | 60,000 |
| V5 | Loa trong | | 141100153 | 60,000 |
| V5 | Ổ SIM | SIM_Card_Connector,, Plug-in,1.3mm | 145500093 | 60,000 |
| V5 | Ổ SIM | SIM_Card_Connector,Plug-in,1.3mm | 145500101 | 60,000 |
| V5 | Loa ngoài | Speaker,9*16*3mm,Shrapnel | 140300031 | 80,000 |
| V5 | Loa ngoài | | 140300039 | 80,000 |
| V5 | Ổ thẻ nhớ | T_Flash_Connector,Lift,1.6mm | 145600011 | 60,000 |
| V5 | Chân sạc | USB_Connector,micro 5pin | 145200077 | 60,000 |
| P6 | Mainboard | Main_PCBA,8Layer | 181002495 | 1,140,000 |
| P6 | Màn hình | TFT_LCD,5.0",FWVGA | 160000576 | 350,000 |
| P6 | Cảm ứng | TP_Assy,5.0",White | 166300103 | 330,000 |
| P6 | Loa Trong | Receiver,6*12*2.25mm,Shrapnel | 141100153 | 60,000 |
| P6 | Loa Trong | Receiver,6*12*2.25mm,Shrapnel | 141100167 | 60,000 |
| P6 | Camera sau | 5M_Camera,AF,OV5648 | 150400068 | 240,000 |
| P6 | Camera trước | 2M_Camera,FF,HI258 | 150200100 | 120,000 |
| P6 | Loa ngoài | Speaker,13*18*2.5mm,Shrapnel | 140300045 | 100,000 |
| P6 | Khung sườn sau + Ăngten Wifi/Gps | GSM/WCDMA/BT/WIFI/GPS_Antenna+B_Cover,W | 170701292 | 170,000 |
| P6 | Vỏ mặt trước | A_Cover_Assy,White | 310101645 | 200,000 |
| P6 | Nắp Pin | Battery_Cover_Assy,White | 314100784 | 140,000 |
| P6 | Phím nguồn | Power_Keypad,White | 320301173 | 60,000 |
| P6 | Nút âm lượng | Volume_Keypad,White | 320301174 | 60,000 |
| P6 | Thấu kính camera | Back_Camera_Lens,Black | 360200899 | 60,000 |
| P6 | Tấm dán bảo vệ | TP_Protective_Film | 351601302 | 20,000 |
| P6 | Màn loa trong | Receiver_Back_Dustproof_Net,Black | 351400734 | 60,000 |
| P6 | Battery | Battery,Orange,315876HV,2000mAh | 200200422 | 210,000 |
| P6 | Battery | Battery,Orange,315877PH,1950mAh | 200200458 | 210,000 |
| P6 | Củ sạc | Charger,100-240V,DC5.0V-1000mA,White | 202000769 | 80,000 |
| P6 | Cáp USB | USB_Cable,Micro_5pin,White | 201000259 | 30,000 |
| P6 | Tai nghe | Earphone,White | 203000459 | 70,000 |
| P6 | Tai nghe | Earphone,White | 203000546 | 70,000 |
| P6 | Tấm dán bảo vệ | Protective_Film_Set | 380800025 | 20,000 |

| | | | | |
|------|---|---|-----------|-----------|
| P6 | Bao da | Leather_Cover,White+Silver | 412100290 | 70,000 |
| P6 | Bao da | Leather_Cover,White+Silver | 412100288 | 70,000 |
| P6 | Cảm ứng | TP_Assy,5.0",Black | 166300105 | 320,000 |
| P6 | Khung sườn sau + Ăngten Wifi/Gps | GSM/WCDMA/BT/WIFI/GPS_Antenna+B_Cover,B | 170701293 | 170,000 |
| P6 | Vỏ mặt trước | A_Cover_Assy,Black | 310101646 | 200,000 |
| P6 | Nắp Pin | Battery_Cover_Assy,Grey | 314100785 | 340,000 |
| P6 | Nút nguồn | Power_Side_Keypad,Black | 320301175 | 60,000 |
| P6 | Nút âm lượng | Volume_Keypad,Black | 320301176 | 60,000 |
| P6 | Củ sạc | Charger,100-240V,DC5.0V-1000mA,Black | 202000770 | 80,000 |
| P6 | Cáp USB | USB_Cable,Micro_5pin,Black | 201000260 | 30,000 |
| P6 | Tai nghe | Earphone,Black | 203000458 | 70,000 |
| P6 | Tai nghe | Earphone,Black | 203000547 | 70,000 |
| P6 | Bao da | Leather_Cover,Grey+Silver | 412100291 | 80,000 |
| P6 | Bao da | Leather_Cover,Grey+Silver | 412100289 | 80,000 |
| P6 | Khung sườn sau + Ăngten Wifi/Gps | GSM/WCDMA/BT/WIFI/GPS_Antenna+B_Cover,S | 170701463 | 170,000 |
| P6 | Khung sườn sau + Ăngten Wifi/Gps | GSM/WCDMA/BT/WIFI/GPS_Antenna+B_Cover,T | 170701462 | 170,000 |
| P6 | Ổ thẻ nhớ | T_Flash_Connector,Plug-in,1.3mm | 145600053 | 80,000 |
| P6 | Ổ thẻ nhớ | T_Flash_Connector,Plug-in,1.3mm | 145600022 | 80,000 |
| P6 | Ổ SIM | SIM_Card_Connector,Plug-in,1.3mm | 145500084 | 80,000 |
| P6 | Chân sạc | USB_Connector,micro 5pin | 145200074 | 80,000 |
| P6 | Chân sạc | USB_Connector,micro 5pin | 145200021 | 80,000 |
| P6 | Chân sạc | USB_Connector,micro 5pin,2.8mm | 145200084 | 80,000 |
| F103 | Mainboard | Main_PCBA,10Layer | 181002560 | 1,440,000 |
| F103 | Camera trước | 5M_Camera,FF,S5K5E2 | 150400076 | 170,000 |
| F103 | Camera sau | 8M_Camera,AF,OV8858-2A | 150500024 | 310,000 |
| F103 | Loa trong | Receiver,10*07*2.15,Shrapnel | 141100176 | 80,000 |
| F103 | Loa trong | Receiver,7*10*2.15mm,Shrapnel | 141100158 | 80,000 |
| F103 | Loa ngoài | Speaker,11*15*3.0mm,Shrapnel | 140300051 | 90,000 |
| F103 | Cụm ăngten | BT/WIFI/GPS_Antenna+Support,Black | 170701467 | 60,000 |
| F103 | Cụm ăngten GSM+WCDMA+Vỏ đen | GSM/WCDMA/LTE_Antenna+Support,Black | 170701439 | 60,000 |
| F103 | Màn hình + cảm ứng | Preprocess_A_Cover_Assy,Black | 310101810 | 960,000 |
| F103 | Vỏ mặt trước | A_Cover_Assy,Black | 310101811 | 150,000 |
| F103 | Màn hình | LCM,4.99",Black,HD,LCD/CTP | 160300297 | 730,000 |
| F103 | Màn hình | LCM,4.99",Black,HD,LCD/CTP | 160300317 | 730,000 |

| | | | | |
|------|------------------------------------|---------------------------------------|-----------|---------|
| F103 | Màn hình | LCM,4.99",Black,HD,LCD/CTP | 160300299 | 730,000 |
| F103 | Vỏ mặt sau | B_Cover_Assy,Black | 311101213 | 180,000 |
| F103 | Nắp Pin | Battery_Cover_Assy,Black | 314100889 | 160,000 |
| F103 | Phím âm lượng | Volume_Keypad,Silver | 320301263 | 60,000 |
| F103 | Phím nguồn | Power_Keypad,Silver | 320301264 | 60,000 |
| F103 | Thấu kính camera | Camera_Lens | 360101262 | 60,000 |
| F103 | Thấu kính camera | Camera_Lens | 360101318 | 60,000 |
| F103 | Nắp che chân sạc (USB) | USB_Dustproof_Mylar_Sheet | 351200483 | 60,000 |
| F103 | Màn loa trong | Receiver_Dustproof_Net,Black | 351400847 | 60,000 |
| F103 | Tấm dán bảo vệ | TP_Protective_Film | 351601464 | 20,000 |
| F103 | Battery | Battery,Orange,VK355778,2400mAh | 200200562 | 190,000 |
| F103 | Củ sạc | Charger,100-240V,DC5.0V-1000mA,Black | 202000638 | 90,000 |
| F103 | Tai nghe | Earphone,Black | 203000619 | 100,000 |
| F103 | Cáp USB | USB_Cable,Micro_5pin,Black | 201000262 | 40,000 |
| F103 | Cáp USB | USB_Cable,Micro_5pin,Black | 201000260 | 40,000 |
| F103 | Cáp USB | USB_Cable,Micro_5pin,Black | 201000264 | 40,000 |
| F103 | Cáp OTG (On The Go) | OTG_Cable,White | 201000198 | 40,000 |
| F103 | Cáp OTG (On The Go) | OTG_Cable,White | 201000322 | 40,000 |
| F103 | Ốp lưng nhựa | Protective_Case | 412400070 | 20,000 |
| F103 | Tấm dán bảo vệ | Protective_Film_Set | 380800086 | 20,000 |
| F103 | Cụm ăngten | BT/WIFI/GPS_FPC_Antenna+Support,White | 170701417 | 60,000 |
| F103 | Cụm ăngten GSM+WCDMA+Vỏ đen | GSM/WCDMA/LTE_Antenna+Support,White | 170701438 | 60,000 |
| F103 | Màn hình + cảm ứng | Preprocess_A_Cover_Assy,White | 310101808 | 960,000 |
| F103 | Vỏ mặt trước | A_Cover_Assy,White | 310101799 | 150,000 |
| F103 | Màn hình | LCM,4.99",White,HD,LCD/CTP | 160300296 | 700,000 |
| F103 | Màn hình | LCM,4.99",White,HD,LCD/CTP | 160300300 | 700,000 |
| F103 | Vỏ mặt sau | B_Cover_Assy,Silver | 311101191 | 180,000 |
| F103 | Nắp Pin | Battery_Cover_Assy,White | 314100888 | 160,000 |
| F103 | Củ sạc | Charger,100-240V,DC5.0V-1000mA,White | 202000639 | 90,000 |
| F103 | Tai nghe | Earphone,White | 203000615 | 100,000 |
| F103 | Cáp USB | USB_Cable,Micro_5pin,White | 201000259 | 40,000 |
| F103 | Cáp USB | USB_Cable,Micro_5pin,White | 201000261 | 40,000 |
| F103 | Cáp USB | USB_Cable,Micro_5pin,White | 201000263 | 40,000 |
| F103 | Vỏ mặt sau | B_Cover_Assy,Gold | 311101214 | 180,000 |

| | | | | |
|--------|---------------------------|--|-----------|-----------|
| F103 | Phím âm lượng | Volume_Keypad,Gold | 320301292 | 60,000 |
| F103 | Phím nguồn | Power_Keypad,Gold | 320301293 | 60,000 |
| F103 | Ổ thẻ nhớ | T_Flash_Connector,Plug-in,1.3mm | 145600053 | 80,000 |
| F103 | Ổ SIM | SIM_Connector,Plug-in,1.45mm | 145500109 | 80,000 |
| F103 | Chân sạc (USB) | USB_Connector,micro_5pin,2.8mm | 145200084 | 100,000 |
| S PLUS | Mainboard | Main_PCBA,10Layer | 181002639 | 1,950,000 |
| S PLUS | Camera sau | 13M_Camera,AF,S5K3M2XXM5 | 150800024 | 470,000 |
| S PLUS | Camera trước | 5M_Camera,FF,OV5648 | 150400096 | 240,000 |
| S PLUS | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100167 | 90,000 |
| S PLUS | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100166 | 90,000 |
| S PLUS | Loa ngoài | Speaker,13*18*2.5mm,Shrapnel | 140300045 | 130,000 |
| S PLUS | Màn hình + Cảm ứng | Preprocess_A_Cover_Assy,Silver | 310101903 | 1,330,000 |
| S PLUS | Cảm ứng | A_Cover_Assy,Silver | 310101904 | 360,000 |
| S PLUS | Màn hình | LCM, 5.49", HD, LCD/CTP (AMOLED/Black) | 160300323 | 1,050,000 |
| S PLUS | Nắp pin | Battery_Cover_Assy,Gold | 314100919 | 200,000 |
| S PLUS | Phím âm lượng | Volume_Keypad,Gold | 320301316 | 60,000 |
| S PLUS | Phím nguồn | Power_Keypad,Gold | 320301317 | 60,000 |
| S PLUS | Màn hình + Cảm ứng | Preprocess_A_Cover_Assy,Grey | 310101887 | 1,330,000 |
| S PLUS | Cảm ứng | A_Cover_Assy,Grey | 310101872 | 360,000 |
| S PLUS | Nắp pin | Battery_Cover_Assy,Blue_Black | 314100880 | 200,000 |
| S PLUS | Phím âm lượng | Volume_Keypad,Grey | 320301307 | 60,000 |
| S PLUS | Phím nguồn | Power_Keypad,Grey | 320301308 | 60,000 |
| S PLUS | Thấu kính camera | Back_Camera_Lens,Black | 360101303 | 60,000 |
| S PLUS | Thấu kính camera | Back_Camera_Lens,Black | 360101304 | 60,000 |
| S PLUS | Battery | Battery,Orange,376584PH,3150mAh | 200200571 | 220,000 |
| S PLUS | Củ sạc | Charger,100-240V,DC5.0V-1000mA,White | 202000769 | 80,000 |
| S PLUS | Cáp USB-C | TYPE-C_Cable,White | 201800001 | 70,000 |
| S PLUS | Cáp USB-C | TYPE-C_Cable,White | 201800009 | 70,000 |
| S PLUS | Tai nghe | Earphone,White | 203000614 | 130,000 |
| S PLUS | Ốp lưng nhựa | Protective_Case | 412400096 | 40,000 |
| S PLUS | Ổ thẻ nhớ | T_Flash_Connector,Plug-in,1.3mm | 145600053 | 120,000 |
| S PLUS | Ổ SIM | SIM_Connector,Plug-in,1.3mm | 145500107 | 120,000 |
| S PLUS | Chấu sạc USB-C | USB_Connector,TYPE-C_10pin,3.15mm | 145200090 | 120,000 |
| P5W | Mainboard | Main_PCBA,8Layer | 181002681 | 1,050,000 |

| | | | | |
|---------|-----------------------------|--------------------------------------|-----------|-----------|
| P5W | Camera trước | 2M_Camera,FF,GC2355 | 150200110 | 90,000 |
| P5W | Camera sau | 5M_Camera,AF,OV5648 | 150400099 | 190,000 |
| P5W | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100166 | 60,000 |
| P5W | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100167 | 60,000 |
| P5W | Loa ngoài | Speaker,11*15*3.0mm,Shrapnel | 140300072 | 80,000 |
| P5W | Loa ngoài | Speaker,11*15*3.0mm,Shrapnel | 140300073 | 80,000 |
| P5W | Màn hình + Cảm ứng | Preprocess_A_Cover_Assy,Black | 310101938 | 660,000 |
| P5W | Cảm ứng | A_Cover_Assy,Black | 310101939 | 140,000 |
| P5W | Màn hình | LCM,5.0",Black,HD,LCD/CG | 160300340 | 500,000 |
| P5W | Cụm ăngten + B_Cover | GSM/WCDMA/3in1_Antenna+B_Cover,Black | 170701525 | 120,000 |
| P5W | Thấu kính camera | Camera_Lens,Black | 360200972 | 40,000 |
| P5W | Battery | Battery,Orange,VK345674AR,2000mAh | 200101296 | 120,000 |
| P5W | Battery | Battery,Orange,345674AR,2000mAh | 200101302 | 120,000 |
| P5W | Củ sạc | Charger,100-240V,DC5.0V-1000mA,Black | 202000770 | 60,000 |
| P5W | Tai nghe | Earphone,Black | 203000608 | 80,000 |
| P5W | Tai nghe | Earphone,Black | 203000609 | 80,000 |
| P5W | Cáp USB | USB_Cable,Micro_5pin,Black | 201000128 | 40,000 |
| P5W | Cáp USB | USB_Cable,Micro_5pin,Black | 201000235 | 40,000 |
| P5W | Cáp USB | USB_Cable,Micro_5pin,Black | 201000134 | 40,000 |
| P5W | Ốp lưng nhựa | Protective_Case,White | 412400099 | 45,000 |
| P5W | Nắp pin | Battery_Cover_Assy,Black | 314100956 | 110,000 |
| P5W | Nắp pin | Battery_Cover_Assy,Blue | 314100993 | 120,000 |
| P5W | Nắp pin | Battery_Cover_Assy,White | 314100982 | 110,000 |
| P5W | Nắp pin | Battery_Cover_Assy,Yellow | 314100991 | 120,000 |
| P5W | Nắp pin | Battery_Cover_Assy,Green | 314101001 | 120,000 |
| P5W | Nắp pin | Battery_Cover_Assy,Red | 314100992 | 120,000 |
| P5W | Ổ thẻ nhớ | T_Flash_Connector,Simplicity,1.5mm | 145600064 | 90,000 |
| P5W | Ổ SIM | SIM_Connector,Plug-in,1.5mm | 145500112 | 90,000 |
| P5W | Chấu sạc USB | USB_Connectormicro_5pin,2.8mm | 145200074 | 90,000 |
| P5W | Chấu sạc USB | USB_Connector,micro_5pin,2.8mm | 145200084 | 90,000 |
| M5 MINI | Mainboard | Main_PCBA,8Layer | 181002724 | 1,490,000 |
| M5 MINI | Loa ngoài | Speaker,11*15*3.0mm,Shrapnel | 140300072 | 80,000 |
| M5 MINI | Loa ngoài | Speaker,11*15*3.0mm,Shrapnel | 140300073 | 80,000 |
| M5 MINI | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100166 | 60,000 |

| | | | | |
|---------|--|--------------------------------------|-----------|---------|
| M5 MINI | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100167 | 60,000 |
| M5 MINI | Camera sau | 8M_Camera,AF,OV8856 | 150500044 | 260,000 |
| M5 MINI | Màn hình + Cảm ứng + Khung viền | Preprocess_A_Cover_Assy,Black | 310102008 | 940,000 |
| M5 MINI | Khung viền trước | A_Cover_Assy,Tarnish | 310101966 | 200,000 |
| M5 MINI | Màn hình + Cảm ứng | LCM,5.0",Black,HD,LCD/TP | 160300358 | 740,000 |
| M5 MINI | Màn hình + Cảm ứng | LCM,5.0",Black,HD,LCD/TP | 160300359 | 740,000 |
| M5 MINI | Màn hình + Cảm ứng + Khung viền | Preprocess_A_Cover_Assy,Golden | 310102009 | 960,000 |
| M5 MINI | Khung viền trước | A_Cover_Assy,Gold | 310101967 | 240,000 |
| M5 MINI | Màn hình + Cảm ứng | LCM,5.0",Gold,HD,LCD/TP | 160300356 | 720,000 |
| M5 MINI | Màn hình + Cảm ứng | LCM,5.0",Gold,HD,LCD/TP | 160300357 | 720,000 |
| M5 MINI | Màn hình + Cảm ứng + Khung viền | Preprocess_A_Cover_Assy,Silver | 310102007 | 960,000 |
| M5 MINI | Khung viền trước | A_Cover_Assy,Silver | 310101961 | 240,000 |
| M5 MINI | Màn hình + Cảm ứng | LCM,5.0",White,HD,LCD/TP | 160300354 | 720,000 |
| M5 MINI | Màn hình + Cảm ứng | LCM,5.0",White,HD,LCD/TP | 160300355 | 720,000 |
| M5 MINI | Khung sau | B_Cover_Assy,Silver | 311101271 | 130,000 |
| M5 MINI | Nắp Pin | Battery_Cover_Assy,White | 314100983 | 180,000 |
| M5 MINI | Khung sau | B_Cover_Assy,Gold | 311101276 | 130,000 |
| M5 MINI | Nắp Pin | Battery_Cover_Assy,Gold | 314100989 | 180,000 |
| M5 MINI | Phím nguồn + âm lượng | Side_Keypad_Assy,Gold | 320301354 | 60,000 |
| M5 MINI | Khung sau | B_Cover_Assy,Tarnish | 311101275 | 130,000 |
| M5 MINI | Nắp Pin | Battery_Cover_Assy,Black | 314100988 | 180,000 |
| M5 MINI | Phím nguồn + âm lượng | Side_Keypad_Assy,White | 320301350 | 60,000 |
| M5 MINI | Thấu kính camera | Back_Camera_Lens,Silver | 360200978 | 60,000 |
| M5 MINI | Nắp che cảm biến | Light_Sensation_Rubber_Cover,Black | 340200713 | 60,000 |
| M5 MINI | Màn loa ngoài | Receiver_Dustproof_Net+Foam,White | 351401028 | 60,000 |
| M5 MINI | Màng bảo vệ màn hình | TP_Protective_Film | 351601565 | 20,000 |
| M5 MINI | Camera trước | 5M_Camera,FF,S5K5E2 | 150400101 | 150,000 |
| M5 MINI | Battery | Battery,Orange,EBT475885PV,4000mAh | 200200693 | 260,000 |
| M5 MINI | Battery | Battery,Silver,VK485985PH,4000mAh | 200200657 | 260,000 |
| M5 MINI | Củ sạc | Charger,100-250V,DC5.0V-2000mA,White | 202000912 | 100,000 |
| M5 MINI | Tai nghe | Earphone,White | 203000459 | 100,000 |
| M5 MINI | Tai nghe | Earphone,White | 203000546 | 100,000 |
| M5 MINI | CápUSB | USB_Cable,Micro_5pin,White | 201000259 | 80,000 |
| M5 MINI | CápUSB | USB_Cable,Micro_5pin,White | 201000261 | 80,000 |

| | | | | |
|---------|--------------------------------|---|-----------|---------|
| M5 MINI | Ốp lưng | Protective_Case,White | 412400101 | 30,000 |
| M5 MINI | Ổ thẻ nhớ | Combine_Connector,SIM_Card_+T_Card_2In1 | 146000028 | 80,000 |
| M5 MINI | Ổ SIM | SIM_Connector,Plug-in,1.3mm | 145500108 | 80,000 |
| M5 MINI | Chấu sạc USB | USB_Connector,micro 5pin,2.8mm | 145200094 | 80,000 |
| P5 MINI | Mainboard | WBW5617GS,Main_PCBA,6Layer | 181002804 | 940,000 |
| P5 MINI | Camera trước | 2M_Camera,FF,GC2355C | 150200112 | 90,000 |
| P5 MINI | Camera sau | 5M_Camera,AF,HI-545 | 150400102 | 170,000 |
| P5 MINI | Camera sau | 5M_Camera,AF,HI-545 | 150400103 | 170,000 |
| P5 MINI | Loa ngoài | Speaker,11*15*3.0mm,Shrapnel | 140300072 | 60,000 |
| P5 MINI | Loa ngoài | Speaker,11*15*3.0mm,Shrapnel | 140300073 | 60,000 |
| P5 MINI | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100166 | 60,000 |
| P5 MINI | Loa trong | Receiver,6*12*2.25mm,Shrapnel | 141100167 | 60,000 |
| P5 MINI | Màn hình + Cảm ứng | Preprocess_A_Cover_Assy,Black | 310101985 | 500,000 |
| P5 MINI | Khung trước | A_Cover_Assy,Black | 310101986 | 130,000 |
| P5 MINI | Màn hình | LCM,4.5",IPS,LCD/TP(Oncell_Black) | 160300366 | 390,000 |
| P5 MINI | Nắp pin | Battery_Cover_Assy,Blue | 314101016 | 110,000 |
| P5 MINI | Nắp pin | Battery_Cover_Assy,Black | 314101013 | 100,000 |
| P5 MINI | Nắp pin | Battery_Cover_Assy,White | 314101012 | 100,000 |
| P5 MINI | Thấu kính camera | Back_Camera_Lens,Black | 360200979 | 40,000 |
| P5 MINI | Màn loa trong | Receiver_Back_Dustproof_Net,Black | 351401050 | 40,000 |
| P5 MINI | Tấm dán bảo vệ màn hình | TP_Protective_Film | 351601628 | 10,000 |
| P5 MINI | Battery | Battery,Orange,J395763ART,1850mAh | 200101316 | 120,000 |
| P5 MINI | Battery | Battery,Orange,395763AR,1850mAh | 200101317 | 120,000 |
| P5 MINI | Củ sạc | Charger,100-240V,DC5.0V-1000mA,Black | 202000770 | 60,000 |
| P5 MINI | Tai nghe | Earphone,Black | 203000608 | 60,000 |
| P5 MINI | Tai nghe | Earphone,Black | 203000609 | 60,000 |
| P5 MINI | Cáp sạc | USB_Cable,Micro_5pin,Black | 201000128 | 40,000 |
| P5 MINI | Cáp sạc | USB_Cable,Micro_5pin,Black | 201000235 | 40,000 |
| P5 MINI | Ốp lưng bảo vệ | Protective_Case,White | 412400109 | 30,000 |
| P5 MINI | Ổ SIM/Thẻ nhớ | Combine_Connector,Dual_SIM_T_Card_3In1 | 146000033 | 120,000 |
| P5 MINI | Chân sạc USB | USB_Connector,micro 5pin,2.8mm | 145200094 | 100,000 |